

## Fragments

Scanning protocols, coordinate systems, and data formats mirror those used for the [full scrolls](#). Every fragment dataset contains:

- **3D X-ray volumes** at several resolutions / beam energies.
- **Multispectral photographs** (RGB + IR).
- **Hand-labeled ink masks** for at least one surface volume, suitable for supervised ML.

We group the fragments by the facility where they were scanned:

1. **DLS Fragments (2023)** – Six fragments scanned at Diamond Light Source (UK).
2. **ESRF Fragments (2025)** – Three fragments scanned on beamline BM18 at the European Synchrotron Radiation Facility (Grenoble, FR).

**Work-in-progress** 🧑‍🔬 File formats, folder names, and alignment conventions may still shift. Expect additional volumes, surface volumes and meshes and ink labels to appear over time!

---

### 1 • DLS (Diamond Light Source) Fragments

The first six fragments to be released. They were scanned at Diamond Light Source. For more technical details, see [Educelab-Scrolls: Verifiable Recovery of Text from Herculaneum Papyri using X-ray CT](#) and [Educelab Herculaneum Scroll Data \(2023\) Info Sheet](#).

⚠️ 3D x-ray scan volumes of Fragments 5-6 are aligned, but Fragments 1-4 are NOT aligned.

#### Fragment 1 (PHerc. Paris 2 Fr 47)

Fragment 1 (PHerc. Paris. 2 Fr 47)

Volume [20230205142449](#): 3.24µm, 54keV, 7219 x 20MB .tif files. Total size: 145 GB

Volume [20230213100222](#): 3.24µm, 88keV, 7229 x 24MB .tif files. Total size: 171 GB

#### Fragment 2 (PHerc. Paris 2 Fr 143)

Fragment 2 (PHerc. Paris. 2 Fr 143)

Volume [20230216174557](#): 3.24µm, 54keV, 14111 x 46MB .tif files. Total size: 645 GB

Volume [20230226143835](#): 3.24µm, 88keV, 14144 x 43MB .tif files. Total size: 599 GB

### **Fragment 3 (PHerc. Paris 1 Fr 34)**

Fragment 3 (PHerc. Paris. 1 Fr 34)

Volume [20230212182547](#): 3.24µm, 88keV, 6650 x 20MB .tif files. Total size: 134 GB

Volume [20230215142309](#): 3.24µm, 54keV, 6656 x 18MB .tif files. Total size: 121 GB

### **Fragment 4 (PHerc. Paris 1 Fr 39)**

Originally held back for automated scoring in the [Kaggle](#) competition, this fragment has since been released.

Fragment 4 (PHerc. Paris. 1 Fr 39)

Volume [20230215185642](#): 3.24µm, 54keV, 9231 x 23MB .tif files. Total size: 211 GB

Volume [20230222173037](#): 3.24µm, 88keV, 9209 x 24MB .tif files. Total size: 216 GB

### **Fragment 5 (PHerc. 1667 Cr 1 Fr 3)**

From the same original scroll as Scroll 4 (PHerc. 1667), which was partially opened in 1987 using the Oslo method. Find this fragment on [Chartes.it](#).

Fragment 5 (PHerc. 1667 Cr 1 Fr 3)

Volume [20231121133215](#): 3.24µm, 70keV, 7010 x 13MB .tif files. Total size: 87 GB

Volume [20231130111236](#): 7.91µm, 70keV, 3131 x 3MB .tif files. Total size: 8.5 GB

### **Fragment 6 (PHerc. 51 Cr 4 Fr 8)**

Fragment 6 (PHerc. 51 Cr 4 Fr 48)

Volume [20231121152933](#): 3.24µm, 53keV, 8855 x 29MB .tif files. Total size: 253 GB

Volume [20231130112027](#): 7.91µm, 53keV, 3683 x 6MB .tif files. Total size: 21 GB

Volume [20231201112849](#): 3.24µm, 88keV, 8855 x 29MB .tif files. Total size: 253 GB

Volume [20231201120546](#): 3.24µm, 70keV, 8855 x 29MB .tif files. Total size: 253 GB

Show tiny-fragment context photo

---

## 2 · ESRF Fragments (BM18, Grenoble — May 2025)

Between **6 May 2025** and **12 May 2025** we scanned three additional fragments on the brand-new **BM18** 4th-generation beamline at the European Synchrotron Radiation Facility. Phase-contrast helical CT, ultrafine 2.2  $\mu\text{m}$  voxels, and generous sample-to-detector distances were explored to squeeze out every bit of ink contrast.

👉 **Draft info-sheet:** [ESRF Fragment Data \(May 2025\)](#)

\*All ESRF volumes are published as **OME-Zarr** (six-level multiscale) rather than loose TIFF stacks.

**Fragment 500P2**



PHerc. 500P2 – infrared

- 2.215  $\mu\text{m}$ , 110 keV · OME-Zarr
- 4.317  $\mu\text{m}$ , 111 keV · OME-Zarr
- Multispectral stack (16 bands, 420–1050 nm)
- Case + mesh STL (nylon 12 print-ready)

**Fragment 343P**



PHerc. 343P – infrared

- 2.215  $\mu\text{m}$ , 111 keV · OME-Zarr
- 4.320  $\mu\text{m}$ , 116 keV (bin $\times$ 2) · OME-Zarr
- Multispectral stack (16 bands)
- Case + mesh STL

**Fragment 9B**



PHerc. 9B – infrared

- 4.320  $\mu\text{m}$ , 116 keV (bin $\times$ 2) · OME-Zarr
- Multispectral stack (16 bands)
- Case + mesh STL

**Preliminary ink detection** – Our TimesFormer ML models already pick up discrete strokes in the 2.2  $\mu\text{m}$  volumes of 343P and 500P2. For a sneak-peek see the [blog post](#). Surface volumes & precise IR alignment are coming soon.

---

### Data format at a glance

**Work-in-progress** 🧑🏻‍💻 File formats, folder names, and alignment conventions may still shift. Expect additional volumes, surface volumes and meshes and ink labels to appear over time!

/fragments/ # EduceLab classic datasets (TIFF stacks)

```
└─ Frag1/PHerc... .volpkg/
  ├── config.json # metadata
  ├── volumes/ # multiple resolutions / energies
  │   └─ 202302.../0000.tif ...
  └─ working/
      └─ 54keV_exposed_surface/
          ├── surface_volume/00.tif ...
          ├── ir.png
          ├── inklabels.png
          └─ alignment.psd
```

/fragments/ # ESRF 2025 datasets (OME-Zarr)

```
└─ PHerc0500P2/
  ├── 2.215um_HEL_TA_0.4m_110keV.zarr/
  ├── 4.317um_HA_... .zarr/
  ├── paths/ # surface volumes (WIP)
  ├── multispectral/
  └─ cases/ # STL meshes & 3D-printed holders
```

- **Fragments 1-6** use the original *TIFF-stack* .volpkg layout.

⚠ **ESRF fragments** ship as **OME-Zarr multiscale** volumes for instant cloud streaming.

⚠ All infrared & multispectral images are supplied *pre-aligned* where possible. Otherwise, check the alignment.psd layers.

---

## Training of ML models for ink detection

The idea is to train ML models on the fragments, since we have the ground truth data of where the ink is (in addition to the [“crackle” method](#)). Then, those ML models can be applied to the scrolls.

At a high level, training on a fragment works like this:

From a fragment (a) we obtain a 3D volume (b), from which we segment a mesh (c), around which we sample a surface volume (d). We also take an infrared photo (e) of the fragment, which we align (f) with the surface volume, and then manually turn into a binary label image (g). For more details, see [Tutorial 5](#).

---

## **License**

Fragment datasets are released under different licenses. We encourage you to abide by the related dataset license before working on it.